



## HP-N Wick

This self-trimming wick is often used in paraffin wax, palm, and soy candles. Since the HP-N is self-trimming, this is an option for candles with heavily scented wax blends. Made of 100% cellulose fibers, the long strands of tightly braided cotton help reduce afterglow.

### Features:

- ❖ Constructed from 100% of cellulose fiber.
- ❖ Designed for use in various paraffin wax, palm, soy, and heavily scented wax blends.
- ❖ Engineered as a self-trimming wick, minimize soot, reduce carbon deposit and afterglow.

Wick Designation	Yield (yds/lb)	ROC (oz/hr)	Flame Height (inches)	Pool Diameter (inches)
HP 320 N	320	0.13	0.98	1.46
HP 292 N	292	0.16	1.18	1.81
HP 264 N	264	0.17	1.38	1.85
HP 256 N	256	0.17	1.38	1.85
HP 216 N	216	0.18	1.42	1.85
HP 205 N	205	0.18	1.5	1.85
HP 184 N	184	0.21	1.54	2.05
HP 171 N	171	0.23	1.97	2.28
HP 161 N	161	0.24	1.97	2.28



Wicks Unlimited, Inc. warrants that the information contained in this catalog is true and correct to the best of our knowledge. Wicks Unlimited, Inc. is not responsible for any errors or omissions. Customers are strongly recommended to conduct exhaustive burn tests in their own laboratories using samples for their future formal reference. The information of candle testing and data provided herein is not to be overstated.

Wick Designation	Yield (yds/lb)	ROC (oz/hr)	Flame Height (inches)	Pool Diameter (inches)
HP 133 N	133	0.24	2.01	2.28
HP 124 N	124	0.24	2.01	2.32
HP 122 N	122	0.24	2.01	2.32
HP 111 N	111	0.25	2.05	2.32
HP 106 N	106	0.26	2.13	2.32
HP 94 N	94	0.26	2.28	2.36
HP 85 N	85	0.26	2.52	2.76

## Disclaimer

The rate charts provided in this document are meant to serve only as a guide for our customers to assist them in wick selection. Many variables exist in candle wax types, additives and formulations for individual candle systems. Final wick selection should always be confirmed through the customer's own testing process to determine if a particular wick is the correct choice for a particular candle system. Wicks Unlimited is not responsible for selections made by the customer using any of the reference material contained in this catalog. For optimal burn performance in specific candle systems, we strongly recommend that customers conduct exhaustive burn tests in their own burn lab and consider retaining samples for their future internal reference. The importance of candle testing and data validation cannot be overstated.



ASTM  
INTERNATIONAL



Contact US



+ (1) (954) 946-3500



+ (1) (954) 545-7427



sales@wicksunlimited.com



wicksunlimited.com