

10.0 mm Length

Candle manufacturers use Wicks Unlimited's 10.0 mm sustainers worldwide to create tabbed wicks from waxed wick on reels. All of our sustainers are manufactured from .010" (0.254 mm) thick tin-coated steel that helps inhibit corrosion and are preferred by leading candle manufacturers worldwide. These sustainers feature an overall neck height of 10.0 mm, with base diameters ranging from 15.0 to 20.0 mm. It features a wick insertion hole with diameters ranging from 2.1 mm to 3.0 mm to meet your specific requirements.

Features:

- ❖ 10.0 mm neck height
- ❖ Available with either a 15.0 mm or 20.0 mm base diameter for easy gluing.
- ❖ Wick insertion hole diameters from 2.1 mm to 3.0 mm to meet your specific requirements.

- ❖ 10.0 mm sustainers are manufactured from .010" (0.254 mm) thick tin-coated steel that helps inhibit corrosion and are preferred by leading candle manufacturers worldwide.
- ❖ To meet your specific requirements, 10.0 mm sustainers are available with puncture or non-puncture crimping.
- ❖ 10.0 mm sustainers are often found in pillars and containers.



10.0 mm Length

Sustainer	Base Diameter	Overall Height	Hole Diameter
A3798	15.0 mm .590"	10.0 mm .394"	2.4 mm .094"
A3777	15.0 mm .590"	10.0 mm .394"	3.0 mm .118"
A3961	20.0 mm .788"	10.0 mm .394"	2.1 mm .083"
A3800	20.0 mm .788"	10.0 mm .394"	2.4 mm .094"
A3799	20.0 mm .788"	10.0 mm .394"	3.0 mm .118"

Disclaimer

The rate charts provided in this document are meant to serve only as a guide for our customers to assist them in wick selection. Many variables exist in candle wax types, additives and formulations for individual candle systems. Final wick selection should always be confirmed through the customer's own testing process to determine if a particular wick is the correct choice for a particular candle system. Wicks Unlimited is not responsible for selections made by the customer using any of the reference material contained in this catalog. For optimal burn performance in specific candle systems, we strongly recommend that customers conduct exhaustive burn tests in their own burn lab and consider retaining samples for their future internal reference. The importance of candle testing and data validation cannot be overstated.



ASTM
INTERNATIONAL

